

Congratulations on your Wicky Wax Candle Studio
Limited Edition Purchase!



Directions:

Step 1: PREPARE: Gather the materials needed from your box. Place your warning sticker on the bottom of the vessel and lay out wax paper. Everything is included but you will need the use of a microwave, a timer and scissors. If microwave is not available then you will need to use the stove – you will need two pots, one larger than the other and a candy thermometer. You will do the *double boiler method*.*.

Step 2: HEAT YOUR WAX CAREFULLY: IN A MICROWAVE: Place the wax in the pour pot and place both in the microwave for 2 minutes and 40 seconds (if you have more than one kit, add one minute per additional pour pot with wax). If not melted, continue in 20 second increments in the microwave. **ON THE STOVE: *Double boiler method****. Two pots are needed, one that fits inside the other. Fill the larger pot ¼ full of water. Place second pot in the larger pot. Place wax in the smaller of the pots. Turn stove on medium heat and monitor until the wax gets to 185 degrees. Then remove from heat and wait until temperature returns to 130 degrees. Then pour into your pour pot.

Step 3: WAIT FOR THE WAX TO COOL: Place the wax aside to cool, set the timer for twenty minutes. In the meantime...

Step 4: WICK YOUR VESSEL: Remove the backing from the wick sticker and place on the bottom of the wick. Place the top of the wick in the straw – pinch the straw in the middle to maintain control of the wick. Turn the vessel up and eyeball the center or leave it down whichever is more comfortable for you. Adhere the wick to the bottom center inside of the vessel.

Step 5: ADD FRAGRANCE OIL: Once the twenty minute timer goes off - add the entire bottle of fragrance oil to the wax.

Step 6: STIR: Stir the scented wax for TWO full minutes at a medium tempo.

Step 7: POUR: Pour your scented wax into your vessel slowly to avoid air bubbles.

Step 8: CENTER YOUR WICK: Place the craft sticks horizontally in the shape of a triangle on the rim of the vessel to ensure the wick dries with the wick centered in the candle. Build a fort around it.

Step 9: TRIM: **The next day** trim your wick to ¼ inch.

Step 10: BE PATIENT: Wait two days to light. The candle needs to cure.

929.400.5008

Congratulations – you are a chandler!!!

www.wickywaxcandles2@gmail.com

www.wickywaxcandle.com

Need help - call or email.

